


CONGRATULATIONS ON PURCHASING YOUR TOTALLY WICKED AIO 2 ELECTRONIC CIGARETTE KIT



USING YOUR AIO 2

Priming and installing the atomizer head

Note: It is important to “prime” a new atomizer head before first use. Failure to do so can cause the atomizer coil to overheat, leading to an unpleasant taste and sometimes irreversible damage to the atomizer head.

To install an atomizer head, unscrew the cap assembly by pushing down on the airflow control ring, and turning anti-clockwise. Prime one of the atomizer heads by dripping a few drops of e-liquid into the centre of the atomizer head. Screw the atomizer head onto the cap until firmly seated. Fill the tank as directed in the following instructions.

Filling the tank

To fill the device, simply remove the cap assembly and fill the tank, being careful not to exceed the designated max fill line. Screw the cap assembly back into the tank.

NOTE: It is important not to fill beyond the max fill line, as this will cause e-liquid to overflow when the cap assembly is installed.

NOTE: After priming a new atomizer head and filling the tank, it is recommended to wait 5 minutes to ensure the atomizer head is fully saturated.

Changing the atomizer head

To change the atomizer head, unscrew the cap assembly. Unscrew and dispose of the old atomizer head. Prime the new atomizer head and refit following the directions in *Priming and installing the atomizer head*.

Power on and off / Changing the tank LED colour

To turn the device on or off, quickly press the power button 5 times. The LED will flash 5 times quickly to confirm your selection.


To change the colour of the LED displayed in the tank, turn the device off and hold the power button until the LED illuminates. Then press the power button repeatedly to cycle through the colours: blue, green, indigo, red, purple, yellow, white, or no light. Release the power button to confirm your selection.

Vaping

Press and hold the power button as you inhale the vapour. The LED will illuminate while the power button is held down to vape.

Charging the battery

To charge the battery, connect the charge lead to the USB port. The LED at the bottom of the tank will glow red and simultaneously flash 5 times in your chosen colour when the charge lead is first connected. Once charging, the LED will continue to glow red until fully charged, at which point it will turn off.



Battery level indication

Approximately one second after the power button is released, the LED will relight to show the battery's approximate remaining charge as detailed in the table.

Battery Percentage	LED Condition
100-60%	Continuously lit
59 – 30%	Flashes slowly
29 – 10%	Flashes moderately
9 – 0%	Flashes quickly

Adjustment of airflow:

Adjust the airflow by turning the airflow control ring. When the triangle indentation on the ring is aligned with the indentation just below the mouthpiece, the airflow is fully open. Rotating the ring either clockwise or anti-clockwise by 90° will minimise the airflow. To find your preferred airflow adjust the ring between 0 - 90°.

PROTECTIONS

Short circuit protection

If a short circuit occurs before the power button is pressed, the LED will flash 5 times. If a short circuit occurs while the power button is pressed, the LED will flash 3 times. Replacing the atomizer head should allow normal operation to resume. Follow the steps outlined in *Changing the atomizer head*.

Atomizer protection

If the power button is held down for longer than 15 seconds, the device will stop producing any vapour and the power LED will flash 10 times. After releasing the power button normal operation will resume.

Low voltage protection

If the battery voltage drops below 3.3V, the LED will flash 20 times and the device will power off. Charge the device via USB to power it back on.

KIT CONTENTS

1 x Totally Wicked AIO 2
2 x BF SS316 1.5ohm atomizer head
1 x USB cable
1 x User manual
Spare parts

Specifications:

Dimensions: 119.0mm (length) x 19.0mm (diameter)
Weight: 71g
Battery capacity: 1500mAh
Output modes: Direct output
Tank/Battery connection: All in one
Tank capacity: 2.0ml
Filling method: Screw top fill with child-lock
Airflow type: Top adjustable
Atomizer head resistance compatibility: 0.3 – 3.0ohm
Max refill nozzle diameter: 12mm

ADDITIONAL PRODUCT INFORMATION

There are no reported medical side effects with this product. If you believe you experience a side effect, please contact the manufacturer.

PRODUCT STORAGE AND BATTERY PRECAUTIONS

- Store the AIO 2 and its accessories away from children when not in use.
- Ensure the AIO 2 is powered off when not in use.
- Avoid accidentally pressing the AIO 2 power button when not in use.
- Please only use the charging cable provided.
- Please dispose of dead batteries in accordance with your country's appropriate legislation.
- Do not charge the batteries in a damp environment.
- Do not use the device when temperatures are outside the range -10 - 60°C.
- Do not charge the battery when temperatures are outside the range 0 - 45°C.
- Do not attempt to repair a faulty AIO 2 as these are sealed units with no serviceable parts. Attempted repairs will void the warranty.

WARRANTY

The AIO 2 components have a 28-day parts warranty, with the exception of Atomizer Heads, which are consumable items and covered by "dead on arrival" warranty only. The USB cable supplied has a 12-month warranty. If any parts are found to be faulty within this time please contact our customer service team, whose details are on the back page of this booklet and we will arrange for a replacement. We may require the goods to be returned for further investigation.