



TOTALLY WICKED®

# PSYCHE

E-CIGARETTE BATTERY MOD


USER MANUAL



CONGRATULATIONS  
ON PURCHASING YOUR

**TOTALLY WICKED  
PSYCHE  
BATTERY MOD.**

## THE TOTALLY WICKED PSYCHE



## USING YOUR PSYCHE

### **Power on and off:**

Press the power button 5 times in quick succession to turn the Psyche on. To turn the device off, again press the power button 5 times repeatedly.

### **Vaping:**

Press and hold the power button as you inhale the vapour. A puff timer will be displayed on screen.

## USING YOUR PSYCHE

### **Charging the battery:**

To charge the battery, connect the supplied charge lead into a suitable USB connection port, the battery icon on screen will begin to flash with a bolt icon until fully charged.

### **Setting the wattage:**

The Psyche has adjustable wattage that can be set from 1 – 80 watts. Use the adjustment buttons to increase or decrease the wattage output.

## USING YOUR PSYCHE

### **Wattage adjustment lock:**

The Psyche's wattage adjustment can be locked to prevent the wattage from accidentally being altered during use. While the Psyche is powered on, press the up and down adjustment buttons simultaneously for 3 seconds. The screen will display "Lock". Repeating this process will return the device to normal operation, and the screen will display "UnLock".

### **Rotating the display:**

Pressing the up and down buttons simultaneously for 3 seconds when the Psyche is powered off will rotate the screen display through 180°. This can be helpful if you are left-handed.

## USING YOUR PSYCHE

### **Short circuit protection:**

If a short circuit occurs whilst the power button is pressed, the screen will display “ATOMIZER SHORT”. Replacing the atomizer head should allow normal operation to resume.

### **Atomizer protection:**

If the power button is held down for longer than 10 seconds, the device will stop producing any vapour. And a message will appear on screen stating “Over 10s” and the device will power off. 5 clicks of the power button will turn the device back on and allow normal operation to resume.

## USING YOUR PSYCHE

**Note:** It is possible to change the maximum vaping time between 5, 10 and 15 seconds, or to turn this function off entirely. See “Advanced Functions” for more information.

### **Dry Burn Protection:**

The Psyche features automatic Dry Burn Protection (DBP) technology, which prevents atomizer heads from prematurely burning when the e-liquid level is low. This technology is only active with some specific stainless steel coil atomizer heads.

## ADVANCED FUNCTIONS:

RETURN



DISPLAY



STEALTH



PREHEAT



VAPING TIMEOUT



VERSION



BATTERY VOLTAGE





## ADVANCED FUNCTIONS:

The Psyche has a number of advanced functions that can be activated, adjusted or turned off entirely. They are functions that you do not necessarily need, and are consequently held in a hidden menu. If you are not the sort of person that wants to worry about this sort of detail, you can ignore them and use the standard factory settings. However, if you are the sort of person that wants to fully customise your vaping experience, read on!

To enter the advanced function menu press the power button and the up button simultaneously for 3 seconds. You can then use the up and down buttons to scroll along the display and access each function. The first function shown is the **Return** symbol. Pressing the power button with this symbol highlighted, or simply waiting 10 seconds while taking no action, will exit the menu and return the Psyche to normal operation.

## ADVANCED FUNCTIONS:

### Display information:

The Psyche can display a choice of a puff counter, total vaping time or voltage output beneath the atomizer resistance reading. Use the up and down buttons to select the **Display** icon, then press the power button. You can then use the up and down buttons to choose your preferred display information, and select it by pressing the power button. Should you wish to reset the puff counter or the total vaping time, pressing the up button for 3 seconds will set the selected counter to zero. Pressing the power button will return the Psyche to the advanced menu.

## ADVANCED FUNCTIONS:

### Stealth mode:

The Psyche is equipped with provision for “stealth mode”, where normal use will not activate the screen, but a short press of the power button will allow the display to function normally. Pressing the power button when the **Stealth** icon is highlighted allows stealth mode to be turned on or off, using up and down buttons to highlight, and power button to select.

## ADVANCED FUNCTIONS:

### Preheat:

The Psyche's preheat function allows the atomizer head to heat up quickly by providing additional power for a short period as the power button is pressed. To set the preheat, access the menu by holding the up adjustment button and power button simultaneously. Pressing the power button when the **Preheat** icon is highlighted allows you to choose your preferred pre-heat power (Pwr) and heating duration (Dura) up to 2 seconds. Use these settings cautiously, as preheat power much higher than you are normally using can cause damage to your atomizer head. Setting the preheat duration to zero (this is the default setting) disables the preheat function. Preheat power is initially set at 30W.

## ADVANCED FUNCTIONS:

### Vaping timeout:

The maximum vaping time on the Totally Wicked Psyche battery mod can be changed between 5, 10 or 15 seconds, and can also be turned off. Selecting the **Vaping timeout** icon allows settings to be selected.

### Version:

Selecting the **Version** icon allows the current hardware and firmware versions to be displayed.

### Battery Voltage:

Selecting the **Battery Voltage** icon allows the current internal battery cell voltage to be displayed.

**KIT CONTENTS:**

- 1 x Psyche battery mod
- 1 x USB-C cable
- 1 x User manual

**SPECIFICATIONS:**

**Dimensions:** 80.4mm (length) x 36mm (width) x 30.3mm (depth)

**Weight:** 121g

**Battery capacity:** 3000mAh

**Output modes:** Wattage Mode

**Max charging current:** 2.0A

**Wattage range:** 1 – 80W

**Screen size:** 0.86in

**Tank/Battery connection:** 510 connection

## PRODUCT STORAGE AND BATTERY PRECAUTIONS

- Store the Psyche and its accessories away from children when not in use.
- Ensure the Psyche is powered off when not in use.
- Avoid accidentally pressing the Psyche power button when not in use.
- Please only use the charging cable provided.
- Please dispose of dead batteries in accordance with your country's appropriate legislation.
- Do not charge the batteries in a damp environment.
- Do not use the device when temperatures are outside the range -10 - 60°C.
- Do not charge the battery when temperatures are outside the range 0 - 45°C.
- Do not attempt to repair a faulty Psyche as these are sealed units with no serviceable parts. Attempted repairs will void the warranty.

## WARRANTY

The Psyche battery mod has a 28-day parts warranty. The USB cable supplied has a 12-month warranty. If any parts are found to be faulty within this time please contact our customer service team, whose details are on the back page of this booklet and we will arrange for a replacement. We may require the goods to be returned for further investigation.





# PSYCHE

PiLLbOX 38

Manufactured in China under the authority of Pillbox38 UK Ltd,  
Stancliffe Street, Blackburn, Lancashire, BB2 2QR.



Tel 01254 692244  
[www.totallywicked.co.uk](http://www.totallywicked.co.uk)



Tel 0941-78447082  
[www.totallywicked.de](http://www.totallywicked.de)

